

OPERATING INSTRUCTIONS
TOMMY HILFIGER ANALOG/DIGITAL CHRONOGRAPH WATCH-
1/100 OF A SECOND with alarm function



This Tommy Hilfiger analog/digital chronograph features center-mounted analog hour, minute and seconds hands; a two-window/12-digit LCD (liquid crystal display) with daily alarm/hourly chime/snooze function, 1/100 chronograph with split-time function, 12/24-hour time format selection, and EL backlight.

Using the buttons

Press button **A** to activate EL backlight for 3 seconds in any mode.

Press button **B** to move between/select modes.

Buttons **C** and **D** are used to adjust settings and operate the chronograph.

NOTE: Press and release a button repeatedly to advance displayed information in single increments; press and hold button down to advance information in a display rapidly.

To set analog time:

1. Pull crown **T** out to position 2.
2. Turn crown **T** in either direction to set hands to desired time.
3. Push crown **T** back in to position 1, flush against case.

DIGITAL MODES

There are four modes of digital operation: Real Time, Chronograph, Alarm and Time Setting.

To select/change mode:

Use push-button **B** to select/enter desired mode. Each time button **B** is pushed, the mode will change in this sequence: **B** → Real Time (seconds not flashing) → **B** → Chronograph → **B** → Alarm → **B** → Time Setting (seconds flash) → **B** → Real Time (seconds not flashing).

NOTE: Watch will automatically revert to Real Time mode following a minute of inactivity in any other mode.

REAL TIME

Upper digital window displays alpha Weekday/numeric Month/Date (ex: TH 6-23); lower digital window displays numeric Hour/Minute/Seconds (ex: 11:54:17).

CHRONOGRAPH

The chronograph function on your watch can be used to time an event up to 23 hours, 59 minutes and 59.99 seconds in duration.

To operate the chronograph:

1. Press button **B** until you enter Chronograph mode: “ST” appears in upper left display; “00 00 00” appears in lower digital display.
2. Press button **D** to start timing.
3. Press button **D** again to stop/restart/stop the chronograph as many times as desired to measure the total accumulated time for a single event.
3. When chronograph is stopped at end of timing, press button **C** to reset counter to zero.

To take a split time:

1. With chronograph running, press button **C** to take a split time – i.e., read an intermediate time during an ongoing event.
2. Press button **C** again to take a second split time.
3. Repeat step 2 to take any additional split times, as desired.
4. Press button **D** to exit the split count and stop counting.
5. Press button **C** to display all counts.
6. Press button **C** again to reset counter to zero.

DAILY ALARM

The beeper Alarm function on your watch can be set to sound once a day at a programmed time (Alarm) and/or to beep twice on the hour (Chime).

To activate the alarm:

1. Press button **B** until you enter Alarm mode: “AL” appears in upper left display; current alarm time setting appears in lower digital display.
 2. Press button **D** to activate/deactivate Alarm and/or Chime.
- NOTE: When Alarm is activated, a small sound wave symbol (show symbol) appears in upper right corner of lower display; and when Chime is activated, a small bell symbol (show symbol) appears beside it in upper right side of lower display.

To set alarm:

1. Press button **B** until you enter Alarm mode.
2. Press button **C** to select Hour or Minute setting; field for selected setting will flash.
3. Press button **D** to adjust setting to time desired.
4. Press button **C** to confirm setting; field stops flashing.
5. Repeat steps 3 and 4 to adjust remaining Hour or Minute setting, if desired.
6. Press button **B** to return to Real Time mode.

To use snooze feature:

When Alarm sounds, press button **C** or **D** to stop the beeping; then press button **B** to activate/deactivate the snooze function. When snooze feature is turned on, the Alarm will sound again 5 minutes later, then stop beeping automatically after 20 seconds.

TIME SETTING

In addition to Hour, Minute and Seconds, the digital time function on this model also includes a calendar display with Weekday, Month and Date.

To set digital time:

1. Press button **B** until you enter Time Setting mode: Seconds in lower digital display will start to flash.
2. Press button **C** one or more times to select item(s) to be set in the following sequence: Hour → Minute → Month → Date → Day of week → Seconds. Item currently selected will flash.
4. Press button **D** to adjust the flashing item.

NOTES: When setting the “Hour”: “H” in display indicates 24-hour format; “A” or “P” indicates 12-hour format. Continue pressing button **D** to cycle through time in 24-hour format to reach 12-hour display format.

When setting the “Seconds”: Pressing button **D** when displayed Seconds range from 30 to 59 will resets Seconds to 00 and add 1 to the displayed Minutes. If Seconds are in 00 to 29 range when **D** is pressed, they will reset to 00, but Minutes will not change.

6. Press button **B** to exit Time Setting mode.

BACKLIGHT

Press button **A** to activate EL backlight for 3 seconds from any mode.